

USER MANUAL

VIBRATION METER

PCE-VT 3800 / 3900

ENGLISH



User manuals in various languages (français, italiano, español, português, nederlands, türk, polski) can be found via our product search on:
www.pce-instruments.com

SAFETY NOTES

Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. Damage or injuries caused by non-observance of the manual are excluded from our liability and not covered by our warranty.

- » The device must only be used as described in this instruction manual. If used otherwise, this can cause dangerous situations for the user and damage to the meter.
- » The instrument may only be used if the environmental conditions (temperature, relative humidity, ...) are within the ranges stated in the technical specifications. Do not expose the device to extreme temperatures, direct sunlight, extreme humidity or moisture.
- » Do not expose the device to shocks or strong vibrations.
- » The case should only be opened by qualified PCE Instruments personnel.
- » Never use the instrument when your hands are wet.
- » You must not make any technical changes to the device.
- » The appliance should only be cleaned with a damp cloth. Use only pH-neutral cleaner, no abrasives or solvents.
- » The device must only be used with accessories from PCE Instruments or equivalent.
- » Before each use, inspect the case for visible damage. If any damage is visible, do not use the device.
- » Do not use the instrument in explosive atmospheres.
- » The measurement ranges as stated in the specifications must not be exceeded under any circumstances.
- » Non-observance of the safety notes can cause damage to the device and injuries to the user.

We do not assume liability for printing errors or any other mistakes in this manual.

We expressly point to our general guarantee terms which can be found in our general terms of business.

If you have any questions, please contact PCE Instruments. The contact details can be found at the end of this manual.

SYSTEM DESCRIPTION

Device


The vibration meters PCE-VT 38x0 and PCE-VT 39x0 are capable of measuring and monitoring vibration in machine components. The measuring units include vibration acceleration, vibration velocity and vibration displacement. The reading for the set measuring unit can be shown as RMS, peak, peak-peak value or crest factor. These measured values can be used, for instance, to detect machine imbalances and arising bearing damage. Apart from a Hold function which freezes the current measurement value, the device also has a function to show the maximum value. During a measurement, this function displays the highest value measured so far in addition to the current measurement value. Another feature is the automatic evaluation of the measurement value with regards to the ISO standard 10816-3. When this feature is enabled, the current measurement value is classified into one of four defined zones in line with the corresponding limit values and highlighted by a colour. Other features of the PCE-VT 38x0 include a memory for manual measurements and a data logger function for recording measured values over a longer period of time. In addition to the features described above, the PCE-VT 39x0 offers functions for route measurement, calculation of FFT and RPM measurement. With the PC software included in the scope of delivery, the saved data can be imported from the meter and displayed, evaluated and archived accordingly. The meters have an internal LiPo battery that is charged via the USB socket with a common USB mains adaptor and the battery life is approx. 15 ... 20 hours, depending on the set brightness.

1. Display
2. Keypad
3. Sensor connection
4. Vibration Sensor
5. Magnet
6. USB Port



Display (measurement screen)

1. Date and time
2. Battery level
3. Measuring unit
4. Frequency filter
5. Parameter
6. HOLD on/off
7. Measurement value
8. Max value
9. Set ISO group
10. Vibration severity zone



Function keys

Key	Description	Functions
	On/Off	Turn device on/off
	Menu	Open main menu
	Back	Cancel, return, reset max. value
	OK	Confirm
	Hold	Hold current measurement value
	Up	Menu up
	Down	Menu down
	Right	Menu right
	Left	Menu left

SPECIFICATIONS

Technical specifications

Vibration meter PCE-VT 38x0/39x0	
Measurement range	Vibration acceleration 0.0 ... 399.9 m/s ² Vibration velocity 0.0 ... 399.9 mm/s Vibration displacement 0.0 ... 3.9 mm
Parameters	RMS, peak, peak-peak, crest factor
Accuracy Reference frequency 160 Hz	±2 %
Resolution	Vibration acceleration 0.1 m/s ² Vibration velocity 0.1 mm/s Vibration displacement 1.0 µm
Frequency range	Vibration acceleration 10 Hz ... 10 kHz Vibration acceleration 1 kHz ... 10 kHz Vibration velocity 10 Hz ... 1 kHz Vibration displacement 10 Hz ... 200 Hz
Manual storage	99 folders with 50 memory items each
Data logger	Various start/stop triggers Measuring interval 1 s ... 12 h 50 memory items (up to 43200 readings per measurement)
Route measurement (PCE-VT 39x0 only)	100 routes configurable via PC software Up to 100 machines per route, up to 100 measuring spots possible each 1000 readings per measuring spot
FFT (PCE-VT 39x0 only)	2048 FFT lines FFT acceleration: 10 Hz ... 8 kHz FFT velocity: 10 Hz ... 1 kHz
RPM measurement (PCE-VT 39x0 only)	600 ... 50000 RPM
Units	Metric / imperial
Menu languages	English, German, French, Spanish, Italian, Dutch, Portuguese, Turkish, Polish, Russian, Chinese, Japanese
Operating/storage conditions	Temperature: -20 °C ... +65 °C Humidity: 10 ... 95 % RH, non-condensing
Power supply	Internal: rechargeable LiPo battery (3.7 V, 2500 mAh) External: USB 5 VDC, 500 mA

Vibration meter PCE-VT 38x0/39x0	
Battery life	Approx. 15 ... 20 h (depending on display brightness)
Dimensions	165 x 85 x 32 mm
Weight	239 g
Vibration sensor	
Resonance frequency	24 kHz
Transverse sensitivity	≤5 %
Destruction limit	5000 g (peak)
Operating/storage conditions	Temperature: -55 °C ... +150 °C
Housing material	Stainless steel
Mounting thread	¼" - 28 UNF
Dimensions	Ø 17 x 46 mm (PCE-VT 3xxx SENSOR) Ø 29 x 81 mm (PCE-VT 3xxxS SENSOR)
Weight (without cable)	52 g (PCE-VT 3xxx SENSOR) 119 g (PCE-VT 3xxxS SENSOR)

Accessories

PCE-VT 3xxx MAGNET 25

The magnet adaptor PCE-VT-3xxx MAGNET 25 can be used to attach the vibration sensor to magnetic measuring spots.



PCE-VT 3xxxS SENSOR

To make quick measurements at locations which are difficult to access, the handle with an integrated vibration sensor PCE-VT 3xxxS SENSOR can be used in conjunction with the measuring tip PCE-VT-NP.



Measuring tip PCE-VT-NP

Hard-to-access measurement locations can be reached with the measuring tip PCE-VT-NP. The measuring tip should be placed as vertically as possible on the measurement surface in order to achieve accurate measurements.



USB mains adaptor NET-USB-EU


With the USB mains adaptor, the meter can be charged and operated.



GETTING STARTED

Power supply

An internal rechargeable LiPo battery is used to power the vibration meter. With a fully charged battery and depending on the display brightness, a battery life of approx. 15 ... 20 h is possible. The battery is charged via the USB port at the bottom of the meter, using a USB charger. The charging process can be shortened by switching off the meter while charging. The current battery level is displayed in the status bar in the top right corner of the screen. If the battery charge is insufficient for proper operation of the device, the device automatically powers off and the display below is shown.




Preparation

Connect the sensor with the spiral cable to the vibration meter before turning it on and connect the other end of the cable with the sensor connector of the meter. Tighten the knurled nut to ensure proper connection.

The meter recognizes the sensor automatically. If no sensor is connected, "No sensor" will be displayed instead of the reading in the different measuring functions and the corresponding memory functions are deactivated. This indication also helps diagnosing cable breakage.

In order to turn on the device, press the ON/OFF key until the screen backlight turns on and the start-up screen is shown. The start-up screen is shown for about 2 seconds and the device automatically switches to the measurement screen afterwards. The device is turned off by pressing the ON/OFF key until the screen turns off. This icon is displayed on the start-up screen if date and time need to be set:



MENU


The main menu can be reached from any screen by pressing the MENU key. The ARROW keys are used to navigate through the menu items which can be activated with the OK key. The BACK key is used to return from sub menus. The main menu of the PCE-VT 3800 consists of the sub menus Measurement, Data logger, Memory, Settings, Calibration, Manual and Info which are explained in detail below.

Measurement

The sub menu Measurement is used to configure the different options relevant for the measurement: Measuring unit, Parameter, ISO evaluation, Display max value.

Measuring unit


The measuring unit and the respective frequency range can be adjusted in this menu. The options include acceleration a (10 Hz ... 10 kHz), acceleration a (1 kHz ... 10 kHz), velocity v (10 Hz ... 1 kHz) and displacement d (10 Hz ... 200 Hz). This sub menu can also be directly accessed from the main screen by pressing the arrow key LEFT.



Parameter

It is possible to switch between the parameters RMS, peak, peak-peak and crest factor. This sub menu can also be directly accessed from the main screen by pressing the arrow key RIGHT.

- » RMS: Root Mean Square, effective value of the signal
- » Peak: highest absolute value of the signal
- » Peak-peak: difference between highest and lowest value of the signal
- » Crest factor: Quotient of peak and RMS, roughly describes the signal form




ISO evaluation


In order to enable the automatic evaluation of the current measurement value according to the ISO standard 10816-3, the measuring unit vibration acceleration or vibration velocity in conjunction with the parameter RMS must be selected. This is necessary as the ISO standard only lists valid thresholds for these combinations. After selecting the correct options, the appropriate group for the machine can be selected in this menu. The reading will be evaluated according to this group.

When this function is enabled, the name of the activated group is displayed at the bottom of the measuring screen together with a graph of the four vibration severity zones. The current measurement value is categorized into one of the four zones and colour coded according to the thresholds. Additionally, the item which represents the current zone flashes so that the reading can be quickly evaluated with regards to the limit values defined in the standard.

If the ISO evaluation is currently enabled and an incompatible measuring unit (acceleration) or parameter (peak, peak-peak, crest factor) is selected, the evaluation function is automatically disabled and a hint is displayed on the screen.



As described previously, the ISO evaluation function requires the measuring unit velocity or displacement in conjunction with the parameter RMS. Otherwise, the menu to enable this function cannot be opened and the following hint is displayed on the screen.



Machine groups:

- » Group 1: Large machines with nominal power >300 kW;
Electrical machines with shaft height >315 mm
These machines generally have plain bearings and the relatively high rated/operating speeds range from 120 min⁻¹ to 15,000 min⁻¹
- » Group 2: Medium-sized machines with nominal power between 15 kW and 300 kW;
Electrical machines with shaft height 160 mm <H <315 mm.

Vibration velocity		Group 1		Group 2	
mm/s	in/s	rigid	flexible	rigid	flexible
> 11.0	> 0.43	D	D	D	D
7.1 ... 11.0	0.28 ... 0.43		C		
4.5 ... 7.1	0.18 ... 0.28	C	B	C	C
3.5 ... 4.5	0.14 ... 0.18	B			
2.8 ... 3.5	0.11 ... 0.14				
2.3 ... 2.8	0.09 ... 0.11		B	A	
1.4 ... 2.3	0.06 ... 0.09	A			A
< 1.4	< 0.06				

Vibration severity zones for vibration velocity according to DIN ISO 10816-3

Vibration displacement		Group 1		Group 2	
µm	mil	rigid	flexible	rigid	flexible
> 140	> 5.51	D	D	D	D
113 ... 140	4.45 ... 5.51		C		C
90 ... 113	3.54 ... 4.45		C		
71 ... 90	2.80 ... 3.54	C	B	C	B
57 ... 71	2.24 ... 2.80				
45 ... 57	1.77 ... 2.24	B	A	C	B
37 ... 45	1.46 ... 1.77			B	
29 ... 37	1.14 ... 1.46			A	
22 ... 29	0.87 ... 1.14	A		A	B
< 22	< 0.87				

Vibration severity zones for vibration displacement according to DIN ISO 10816-3

Display max value

This sub menu is used to activate the display of the max value. When enabled, the highest reading so far is displayed separately below the current measurement value. The BACK key can be used to reset the max value.

Data logger

In this menu, the data logger can be started and the data logger settings can be changed.

Start data logger

The data logger is started via this sub menu which opens the data logger screen where the current measuring parameters, the reading and the data logger settings are displayed. For the data logger, the same settings as for the general measuring mode are used. These can be changed as described under 5.1 Measurement.

Measuring interval

For the measuring interval, various intervals between 1 s and 12 h are possible.

Start condition

The data logger can either be started manually by a keystroke or automatically at a certain date which is set in this menu.

Stop condition

There are three different options for stopping the data logger. You can either stop the data logger manually by a keystroke, at a certain date or after a set time interval.

Delete data / Delete all

Via these two menu items, either individual data records or all saved data records can be deleted at a time.

Memory

When manual memory is enabled, individual measurements can be saved to the internal memory for later viewing.

Select folder

Here, the current folder for the memory can be selected. A total of 99 folders for 50 individual measurements each is available.

Display data

With the help of these functions, the measurements saved in the currently selected folder can be viewed again.

Delete data / Delete folder / Delete all

These menu items are used to delete an individual measurement or all measurements in the current folder or all measurements in all folders.

Route measurement (PCE-VT 39x0 only)

This menu is used to start saved routes and to display or delete readings belonging to the routes.

Start route

The routes must be configured using the PC software and transferred to the meter. After the routes have been transferred to the device, a single route can be selected and started with this menu item.

Display data

This menu is used to display saved readings from the measuring spots of a route. The navigation has a tree structure and the order is identical to the route configuration when created with the PC software.

Delete all

Via this menu item, all measured values from the respective measuring spots of all routes can be deleted. The routes themselves will remain.

FFT (PCE-VT 39x0 only)

In this menu, the FFT function can be started and saved FFT spectra can be displayed and deleted.

FFT acceleration / FFT velocity

The spectrum can be displayed either for the vibration acceleration or for the vibration velocity.

RPM

With the help of this function, a machine revolution speed can be entered. This value is saved when a spectrum is saved and is also displayed after the transfer to the PC software.

In addition, the integer harmonics of the entered machine speed can be displayed in the spectrum for orientation. The number of harmonics to be displayed can be set from 1 (machine speed only) to a maximum of 11.

If the function „Show harmonics“ is activated in the meter, the harmonics with the parameters set here are displayed in the zoom spectrum as red dashed lines with numbering during the FFT analysis.

Display data

With the help of this function, saved FFT spectra can be viewed again.

Delete data / Delete all

These two menu items can be used to delete individual FFT spectra or all saved spectra at a time.


RPM measurement (PCE-VT 39x0 only)

Via this menu item, the RPM measurement can be started. This function has no further settings.


Calibration

A vibration calibrator capable of generating a reference vibration of 10 mm/s RMS at 159.2 Hz is required for the calibration of the vibration meter. The calibration can be started via the sub menu Calibration.


A code is required to enter this menu in order to prevent an inadvertent overwrite of the current calibration. The required code is **1402**.



After the code request, the required reference vibration is indicated. The sensor of the vibration meter must now be mounted on the vibration calibrator.




After turning on the vibration calibrator and, if required, setting the reference vibration, the hint can be confirmed with the OK key so that the calibration screen opens. This screen shows the required characteristic values of the reference vibration and the current measurement value in green font and in the unit mm/s. It is not necessary to adjust the measuring unit and the parameter specifically for the calibration as only the RMS value of the vibration velocity will be evaluated during this procedure.



ATTENTION:

Verify that the required reference vibration is generated by the vibration calibrator before the calibration is performed!

If the current measurement value compared to the reference vibration exceeds the desired tolerance, a calibration can be carried out by pressing the OK key and confirming the subsequent dialogue.



The calibration is performed automatically and should take only a few seconds. After a successful calibration, the hint "Calibration successful" pops up. The device then returns to the measurement screen.

Settings

Units

In the sub menu Units, you can choose either the International System of Units (SI) or the Anglo-American unit system (US).

Measurement	Unit	Abbreviation
Frequency	Hertz	[Hz], [kHz]
Vibration acceleration	Meter per second squared Feet per second squared	[m/s ²] [ft/s ²]
Vibration speed	Millimeter per second Inch per second	[mm/s] [in/s]
Vibration path	Millimeter Inch	[mm] [in]

Decimal separator

As decimal separator for the readings, you can either select a dot or a comma.

Date & time

This menu is used to change the date and time. The date format can also be changed.

Brightness

In this tab, the display brightness can be adjusted from 10 % to 100 %. Automatic dimming can also be set. After a set time, the display will be dimmed to a lower brightness in order to save energy. Pressing any key will set the brightness back to its original value.

Language

This menu is used to switch between different menu languages. The available languages are English, German, French, Spanish, Italian, Dutch, Portuguese, Turkish, Polish, Russian, Chinese and Japanese.

Auto power off


This option enables the auto power off function. The available time periods are 1 minute, 5 minutes and 15 minutes. After the set time period has elapsed, the device will automatically turn off and pressing any key will reset the timer. It is also possible to disable the auto power off function.

Reset

This menu is used to reset the device to its factory settings. Device settings are separate from the calibration and each can be reset individually by selecting the corresponding menu item.

A reset of the device settings will load default values for the measurement parameters and any remaining menu options. A calibration which may have been performed beforehand is retained.


In order to prevent an inadvertent reset of the calibration, a code is required to enter this menu. The code is the same as for the calibration itself: **1402**.



ATTENTION:

When the calibration is reset, the previously performed and saved calibration will be deleted and a default calibration for the supplied sensor will be selected. It is recommended to perform a calibration after the reset.

The reset must be confirmed via the subsequent confirmation dialogue. The device will automatically re-start after the reset.

**Manual**

This menu shows a QR code. This code can be decoded with a suitable scanner like, for example, a mobile phone and it links directly to this manual.

Info

This menu shows the device name and firmware version.


MEASUREMENT

Measurement screen

After turning on the device, the measurement screen is displayed. The sensor converts the continuously recorded mechanical vibration into an electrical signal which is subsequently evaluated according to the set parameters and displayed as a measured value.

When the meter is started for the first time and after resetting the device settings, the display shows the RMS value of the measured vibration velocity in mm/s.

When measurement parameters are adjusted via the menu, the changed settings are applied and displayed when returning to measurement mode. These will also remain when the meter is turned off and back on. The menus for the measuring unit and the parameters can also be accessed directly from the measuring screen, by using the arrow keys LEFT or RIGHT.



Preparation for the measurement

Before making a measurement, the desired measurement parameters must be set in the menu. These include the measuring unit, the parameter, the unit and, depending on the application, the ISO evaluation or max value.

Making a measurement

To make a measurement, the sensor must be attached to the desired measuring spot using a stud bolt or the magnetic adaptor. When measuring with the optionally available measuring tip, ensure correct alignment.

In measuring mode, the measurement is carried out continuously and the current value is displayed on the screen.


If ISO evaluation is activated, the measured value is automatically assigned to the corresponding zone on the basis of the selected grouping and highlighted in colour so that a quick assessment of the vibration severity is possible. In addition, the corresponding zone flashes periodically.

Memory

By pressing the OK key while the measurement screen is opened, the current measured value can be saved. This is confirmed by a corresponding message at the bottom of the screen. A folder number and the measured value index are displayed. The measured value is displayed in the currently selected folder which can be selected via the menu. A total of 99 folders with 50 readings each is available.

If the maximum number of measurements is already saved in a folder, a message is displayed when an attempt is made to save another measurement. In this case, a different folder can be selected or saved measurements can be deleted.

The saved measurements can be viewed again via the menu item Memory > Display data.



The desired folder must be set beforehand via the corresponding menu. The measurements can also be read out with the PC software.


Saved measurements can be deleted either individually, completely for the current folder or completely for all folders via the corresponding menu items.

DATA LOGGER

With the help of the data logger function, measured values can be logged over a defined period of time. A total of 50 memory locations is available for the saved data records. The PC software must be used to display the data records.

Settings

The same settings are used for the measurement parameters as for the regular measurement mode. These can be set in the Measurement menu. The settings specific to data logger mode are in the Data logger menu.



The storage interval can be set between 1 s ... 12 h. This means that only the measured values within the set interval are saved. The measured value display during logging updates at the same rate as in regular measuring mode.

The data logger can be started in two different ways: either manually via the OK key or a start time can be set via the Start condition menu.

There are three different options for stopping the data logger. These can be selected via the Stop condition menu. It can be stopped manually by pressing the OK key, at a specific time or after a configurable time interval.


The start and stop conditions can be combined in any way.

When selecting date/time as the start or stop condition, the start of the data logger is prevented if the set start/stop time is before the current time or if the stop time is before the start time. In this case, the corresponding settings must be checked and corrected.

After the desired data logger settings have been selected, the data logger can be started.

Measurement

The data logger is started via the menu item Start data logger, which leads to the data logger screen. This screen shows the current measurement parameters, the measured value and the data logger settings.



Depending on the start condition, the data logger starts automatically when the set start time has been reached (if set) or the OK key must be pressed to start the data logger.

An active measurement is indicated by REC in the upper right corner of the screen as well as a flashing red circle.

Depending on the set stop condition, the data logger stops either automatically after reaching the stop time or after the desired duration or after pressing the OK key. Even if a time or duration has been set as the stop condition, an ongoing measurement can always be stopped by pressing the OK key.

Depending on the duration of the recording, make sure that the battery is sufficiently charged. The device can also be operated with the USB charger so that measurements can be made over a long period of time. A successful measurement is confirmed by a corresponding message at the bottom of the screen. At the same time, the start time is displayed for identification purposes. The data records can then be read out from the meter and displayed with the PC software.


ROUTE MEASUREMENT (PCE-VT 39X0 ONLY)

With the help of the route measurement, a regular check is made possible by measuring numerous measuring spots in a certain sequence. The configuration of a route must be done via the PC software, which is described in detail in the corresponding manual.

A route has a tree structure: Thus, up to 100 machines can be assigned to a single route in the first level and up to 100 measuring spots to each individual machine in the second level. In total, up to 100 different routes can be configured. The names of the individual route elements can be freely assigned in the PC software. For each measuring spot, up to 1000 measured values can be saved to enable a trend display.

Start route

After transferring a route to the meter, it can be selected and started via the menu item Start route.



The display shows the name of the route in the upper left corner. To the right of this, there is a percentage figure representing the total progress of the current route measurement. For each recorded measurement, the percentage display changes accordingly. Below this, the currently selected machine or measuring spot name and the measuring parameters for this measuring spot are displayed.



Use the arrow keys LEFT / RIGHT to select the measuring spots and press the OK key to save a measurement. The order of the machines and measuring spots can be changed when configuring the route in the PC software.

If no measured value has yet been recorded for a measuring spot, the name appears in red and changes to green after a measurement. Similarly, the name of a machine appears in red if a measurement has not yet been taken for all associated measuring spots.




For a measurement already made at a measuring spot, a measurement can be repeated, which overwrites the previous reading and must be confirmed in the corresponding dialogue window.




As soon as a measured value has been recorded for all measuring spots, the following dialogue window appears.

If the red X is selected, the route is not yet completed and measurements for previous measuring spots can be overwritten, for example. When the green tick is selected, this route is completed so that it restarts when selected again.




Cancel or interrupt route

It is possible to interrupt a route that has been started and continue it at a later time. This means that the progress and the already recorded measuring spots remain. When the BACK key or the MENU key is pressed, the following dialogue window appears:



Selecting the red X interrupts the route and returns to the menu. Selecting the green tick serves to prematurely complete a route that has not yet been completely measured so that this route starts again from the beginning when selected again. If a route has not yet been completed and is selected again, the following dialogue box appears. This dialogue also appears if the meter is switched off during a route measurement.

To continue the route, the red X must be selected again. This retains the previous progress. If the green tick is selected, the route is restarted with 0 % progress.



Display data

Via the menu item Display data, the individual measuring spots can be selected and the measured values can be displayed. The measuring spot name is displayed in the title and the measuring parameters of this measuring spot are displayed below it. The measured values recorded during the route measurement are displayed in the list below sorted by date and can be scrolled through with the UP / DOWN arrow keys. In addition, the measured values can be imported with the PC software and displayed graphically.

Delete data


Use the menu item Delete all to delete all saved measured values from all measuring spots. The routes themselves remain. In addition, the measured values can also be deleted via the PC software.

FFT (PCE-VT 39XO ONLY)

The FFT analysis is used to display the vibration signal in the frequency range. Thus, either the amplitudes of the vibration acceleration or of the vibration velocity can be displayed in dependence on the frequency. With the FFT analysis, 2048 frequency lines are calculated and different frequency resolutions are possible depending on the maximum frequency of the spectrum.

Operation and display


In the FFT menu, the desired measuring mode – either vibration acceleration or vibration velocity – must be selected.



The selected mode appears at the top left of the display and the current frequency resolution Δf is shown to the right. The frequency resolution Δf depends on the maximum frequency of the spectrum and the following settings are possible for vibration acceleration:

Max. frequency	Frequency resolution Δf
7812 Hz	3.8 Hz
3906 Hz	1.9 Hz
1953 Hz	1.0 Hz
976 Hz	0.5 Hz

For vibration velocity, only the setting Δf 0.5 Hz with a max. frequency of 976 Hz is possible. The different frequency ranges can be changed with the arrow keys UP and DOWN .




Two spectra are shown in the display. The upper spectrum shows an overall view in which the 2048 FFT lines are averaged. The frequency range is displayed below the graph. The lower spectrum Zoom shows the FFT lines without averaging. Due to the screen resolution, only one section of the entire spectrum can be displayed at a time. The section displayed in the zoom view is represented in the overall view by an orange rectangle and the current frequency range is displayed below the spectrum as in the overall view. Above the overall view, the measured value and the frequency of the FFT line with the highest amplitude are displayed in green font. In addition, the maximum in both spectra is shown as a green line. The cursor is operated with the LEFT / RIGHT arrow keys. This displays the amplitude and frequency of the selected FFT line in orange font colour above the zoom view. In the two spectra, the current cursor position is represented by an orange dashed line. With the help of the HOLD key, the current spectrum can be held. This is indicated by the message HOLD in the overall view at the top right. Pressing it again leads back to the live measurement.

RPM

This menu can be used to set how a machine speed and its harmonics are displayed as auxiliary lines in the spectrum. To do this, the RPM and the desired number of harmonics must first be set. The first harmonic represents the fundamental frequency. Up to 11 harmonics can be selected which are displayed in the zoom spectrum as red dashed lines and numbered accordingly.

If the function „Show harmonics“ is activated, the harmonics with the parameters set here are displayed in the zoom spectrum as red dashed lines with numbering during the FFT analysis. This function can also be used to quickly deactivate the display without having to change the RPM settings.



Memory

The current spectrum can be saved by pressing the OK key. Saving is confirmed by a message at the bottom of the screen indicating the time for identification. If a machine speed has been entered, this is also saved and displayed in the statistics field after the transfer with the PC software.

Saved spectra can be reviewed via the Display datamenu. The display and operation are identical to a regular live measurement.

The measurements can either be removed individually with Delete data or completely with Delete all.

RPM MEASUREMENT (PCE-VT 39X0 ONLY)

With this function, the maximum amplitude of the vibration velocity in the measured vibration signal is determined and the corresponding frequency is displayed as RPM and in Hz.

Note: Faulty measurements may occur if there are any interfering factors in the signal at other frequencies.

PC SOFTWARE

With the help of the PC software PCE-VT 3xxx, the saved data of the different measuring functions (manual memory, data logger, route measurement, FFT) can be transferred from the meter to the PC, displayed and archived. The configuration of the routes for the route measurements is only possible via the software. The functions of the PC software are described in a separate manual which can be accessed directly in the programme via the „BOOK“ button.

DISPOSAL

For the disposal of batteries in the EU, the (EU) 2023/1542 directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose. In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company which disposes of the devices in line with law. For countries outside the EU, batteries and devices should be disposed of in accordance with your local waste regulations. If you have any questions, please contact PCE Instruments.

CONTACT INFORMATION

Germany

PCE Deutschland GmbH
Im Langel 26
D-59872 Meschede
Deutschland
Tel.: +49 (0) 2903 976 99 0
Fax: +49 (0) 2903 976 99 29
info@pce-instruments.com
www.pce-instruments.com/deutsch

United Kingdom

PCE Instruments UK Ltd
Trafford House
Chester Rd, Old Trafford
Manchester M32 0RS
United Kingdom
Tel: +44 (0) 161 464902 0
Fax: +44 (0) 161 464902 9
info@pce-instruments.co.uk
www.pce-instruments.com/english

The Netherlands

PCE Brookhuis B.V.
Twentepoort West 17
7609 RD Almelo
Nederland
Telefoon: +31 (0)53 737 01 92
info@pcebenelux.nl
www.pce-instruments.com/dutch

France

PCE Instruments France EURL
2, rue Georges Kuhnmmunch
67250 Soultz-sous-Forêts
France
Tel.: +33 (0) 972 35 37 17
Fax: +33 (0) 972 35 37 18
info@pce-france.fr
www.pce-instruments.com/french

Italy

PCE Italia s.r.l.
Via Pesciatina 878 / B-Interno 6
55010 Loc. Gragnano
Capannori (Lucca)
Italia
Telefono: +39 0583 975 114
Fax: +39 0583 974 824
info@pce-italia.it
www.pce-instruments.com/italiano

United States of America

PCE Americas Inc.
1201 Jupiter Park Drive, Suite 8
Jupiter / Palm Beach
33458 FL
USA
Tel: +1 (561) 320-9162
Fax: +1 (561) 320-9176
info@pce-americas.com
www.pce-instruments.com/us

Spain

PCE Ibérica S.L.
Calle Mula, 8
02500 Tobarra (Albacete)
España
Tel.: +34 967 543 548
info@pce-iberica.es
www.pce-instruments.com/espanol

Turkey

PCE Teknik Cihazları Ltd.Şti.
Halkalı Merkez Mah.
Pehlivan Sok. No.6/C
34303 Küçükçekmece - İstanbul
Türkiye
Tel: 0212 471 11 47
Faks: 0212 705 53 93
info@pce-cihazlari.com.tr
www.pce-instruments.com/turkish

Denmark

PCE Instruments Denmark ApS
Birk Centerpark 40
7400 Herning
Denmark
Tel.: +45 70 30 53 08
kontakt@pce-instruments.com
www.pce-instruments.com/dansk