



“Your Direct Source for Condition Monitoring, Test & Measurement”

www.ReliabilityDirectStore.com

2911 South Shore Blvd. Suite 170, League City, TX USA 77573 Phone: 281-957-5283 Fax: 281-334-4255

Heavy Duty Phase Indicator/DMM

3-phase sequence indicator
 Plus advanced DMM functions including frequency, Capacitance, and Temperature

Features:

- Large 3-1/2 digit display
- DCV, ACV, Capacitance, Frequency, °C/°F Temperature and Phase
- Direction of arrow on display identifies correct or incorrect wiring configuration
- Continuity beeper, Diode tests
- Type K temperature measurements to 752°F (400°C)
- Built-in stand for benchtop use
- Designed for latest US and European safety standards
- Complete with protective holster, color coded test leads for phase, alligator clips, multimeter test leads, bead wire temperature probe (-58 to 482°F/-50 to 250°C), and 9V battery



Complete with color coded test leads for phase.



Specifications:	Range	Accuracy (%rdg+digits)
DC Voltage	2V, 20V, 200V, 600V	±1.2% +1d
AC Voltage	200V, 600V	±2.0% +4d
Capacitance	20n, 200nF, 2000µF, 20mF	±4% +10d
Resistance (Ω)	20Ω, 2K, 20K, 200K, 2000K, 20M, 200M, 2000M	±1%
Frequency	10Hz to 100KHz (auto-ranging)	±0.5%
Temperature	-4 to 752°F (-20 to 400°C)	±2%
Phase Indicator	45 to 450Hz, 80 to 480VAC	
Dimensions	5.7 x 2.7 x 1.5" (145 x 69 x 38mm) with holster	
Weight	12oz (340g)	

Ordering Information:

380224Heavy Duty Phase Indicator/Multimeter
 380224-NISTHeavy Duty Phase Indicator/Multimeter w/NIST
 380995Vinyl Pouch Carrying Case



RELIABILITY DIRECT, INC.
 2911 S. Shore Blvd., Suite 170 League City, TX USA 77573 Tel: 281.957.5283 Fax: 281.334.4255